

Mechanics Review-III

- Elasticity
- Material Models
- Yielding criteria, Tresca and Von Mises
- Levy-Mises equations
- Case Study for multiple failure mechanism

Prof. Ramesh Singh




Elastic Stress-Strain

- Linear stress-strain

$$\sigma_x = E \varepsilon_x$$

- The extension in one direction is accompanied by contraction in other two directions, for isotropic material

$$\varepsilon_y = \varepsilon_z = -\nu \varepsilon_x$$



Prof. Ramesh Singh



Hooke's Law

- In x direction, strain produced by stresses

Strains in x direction due to various stresses

$$\sigma_x \rightarrow \frac{\sigma_x}{E}$$

$$\sigma_y \rightarrow -\frac{\nu \sigma_y}{E}$$

$$\sigma_z \rightarrow -\frac{\nu \sigma_z}{E}$$

Superimposing,

$$\varepsilon_x = \frac{\sigma_x}{E} - \frac{\nu \sigma_y}{E} - \frac{\nu \sigma_z}{E}$$

$$\varepsilon_x = \frac{\sigma_x}{E} - \frac{\nu}{E} (\sigma_y + \sigma_z)$$

Prof. Ramesh Singh



Hooke's Law

$$\varepsilon_x = \frac{\sigma_x}{E} - \frac{\nu}{E} (\sigma_y + \sigma_z)$$

$$\varepsilon_y = \frac{\sigma_y}{E} - \frac{\nu}{E} (\sigma_x + \sigma_z)$$

$$\varepsilon_z = \frac{\sigma_z}{E} - \frac{\nu}{E} (\sigma_x + \sigma_y)$$

$$\tau_{xy} = G \gamma_{xy}$$

$$\tau_{yz} = G \gamma_{yz}$$

$$\tau_{xz} = G \gamma_{xz}$$

Prof. Ramesh Singh



Stiffness Matrix

$$\begin{bmatrix} \sigma_{xx} \\ \sigma_{yy} \\ \sigma_{zz} \\ \sigma_{yz} \\ \sigma_{zx} \\ \sigma_{xy} \end{bmatrix} = \frac{E}{(1+\nu)(1-2\nu)} \begin{bmatrix} 1-\nu & \nu & \nu & 0 & 0 & 0 \\ \nu & 1-\nu & \nu & 0 & 0 & 0 \\ \nu & \nu & 1-\nu & 0 & 0 & 0 \\ 0 & 0 & 0 & 1-2\nu & 0 & 0 \\ 0 & 0 & 0 & 0 & 1-2\nu & 0 \\ 0 & 0 & 0 & 0 & 0 & 1-2\nu \end{bmatrix} \begin{bmatrix} \varepsilon_{xx} \\ \varepsilon_{yy} \\ \varepsilon_{zz} \\ \varepsilon_{yz} \\ \varepsilon_{zx} \\ \varepsilon_{xy} \end{bmatrix}$$

Prof. Ramesh Singh



Compliance Matrix

$$\begin{bmatrix} \varepsilon_{xx} \\ \varepsilon_{yy} \\ \varepsilon_{zz} \\ \varepsilon_{yz} \\ \varepsilon_{zx} \\ \varepsilon_{xy} \end{bmatrix} = \frac{1}{E} \begin{bmatrix} 1 & -\nu & -\nu & 0 & 0 & 0 \\ -\nu & 1 & -\nu & 0 & 0 & 0 \\ -\nu & -\nu & 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 1+\nu & 0 & 0 \\ 0 & 0 & 0 & 0 & 1+\nu & 0 \\ 0 & 0 & 0 & 0 & 0 & 1+\nu \end{bmatrix} \begin{bmatrix} \sigma_{xx} \\ \sigma_{yy} \\ \sigma_{zz} \\ \sigma_{yz} \\ \sigma_{zx} \\ \sigma_{xy} \end{bmatrix}$$

Prof. Ramesh Singh



Poisson's Ratio

- Adding the strains

$$\varepsilon_x + \varepsilon_y + \varepsilon_z = \frac{1-2\nu}{E} (\sigma_x + \sigma_y + \sigma_z)$$

$\frac{\Delta V}{V} = e_x + e_y + e_z$, Engineering strains for elastic condition


- For fully plastic,

$$\varepsilon_x + \varepsilon_y + \varepsilon_z = 0$$

$\nu = 0.5$, Typically, $-1 < \nu < 0.5$, Most metals, 0.3

Prof. Ramesh Singh






Stretching these two-dimensional hexagonal structures horizontally reveals the physical origin of Poisson's ratio. **a**, The cells of regular honeycomb or hexagonal crystals elongate and narrow when stretched, causing lateral contraction and so a positive Poisson's ratio. **b**, In artificial honeycomb with inverted cells, the structural elements unfold, causing lateral expansion and a negative Poisson's ratio.

Constitutive Behavior Equations

Linear elastic (simplest)

- Young's modulus, $E = \sigma/e$



Thomas Young
1773-1829






Robert Hooke
1635-1703

Prof. Ramesh Singh





#2 - Match

- a) Elastic – plastic material
- b) Perfectly plastic material
- c) Elastic – linear strain hardening material



Actual Material Behavior

$$\sigma_t = K \varepsilon^n$$




K = strength coefficient
 n = strain hardening coefficient

Strain Rate Effect (1)

$$\sigma = C \dot{\varepsilon}^m$$

C = strength coefficient

m = strain rate sensitivity coefficient




Prof. Ramesh Singh



Yield Criteria

- How do you know if a material will fail?
Compare loading to various yield criteria
 - Tresca
 - von Mises
- Key concepts
 - plane stress
 - plane strain



Henri Tresca
1814-1885



Richard von Mises
1883-1953

Prof. Ramesh Singh




#3 - Match

- a) Tresca yield criterion
- b) Von Mises yield criterion
- c) Maximum distortion energy criterion
- d) Maximum shear stress criterion

- 1) $\tau_{\max} \geq \frac{1}{2} \sigma_{\text{yield}}$
- 2) $(\sigma_1 - \sigma_2)^2 + (\sigma_2 - \sigma_3)^2 + (\sigma_3 - \sigma_1)^2 = 2Y^2$
- 3) $\sigma_3 - \sigma_1 = 2\tau_{\text{yield}}$

Stress-Strain Relationship

- Strength of a material or failure of the material is determined from uniaxial stress-strain tests
- The typical stress-strain curves for ductile and brittle materials are shown below.



Prof. Ramesh Singh



Need for a failure theory

- In the case of multiaxial stress at a point we have a more complicated situation present. Since it is impractical to test every material and every combination of stresses σ_1 , σ_2 , and σ_3 , a failure theory is needed for making predictions on the basis of a material's performance on the tensile test.

Tresca Yield Criterion

τ_{\max} , k or τ_{yield} (shear yield stress) a material property

From Mohr's circle the radius of the largest circle gives maximum shear stress,

$$(\sigma_1 - \sigma_3)/2 = \tau_{\max} \quad \tau = \frac{\sigma_{\max} - \sigma_{\min}}{2} = k$$

- Simple uniaxial tension

$$\sigma_1 = Y; \sigma_2 = \sigma_3 = 0, \text{ we get } Y = 2 \tau_{\max}$$

Tresca criteria says that the material yields at maximum shear stress

- Yielding under triaxial stress occur at:

$$\sigma_1 - \sigma_3 = Y$$

For design: $\sigma_1 - \sigma_3 = Y/n$ where n is factor of safety




Importance of Yield Criterion

Assume three loading conditions in plane stress:

$$\sigma_1 - \sigma_3 = Y$$

At the onset of yielding,



Prof. Ramesh Singh



Derivation of Distortion Energy

- Done in class

Prof. Ramesh Singh



Von Mises Yield Criterion

Based on Distortion Energy

$$(\sigma_1 - \sigma_2)^2 + (\sigma_2 - \sigma_3)^2 + (\sigma_3 - \sigma_1)^2 = 2Y^2$$


$$(\sigma_x - \sigma_y)^2 + (\sigma_y - \sigma_z)^2 + (\sigma_z - \sigma_x)^2 + 6(\tau_{xy}^2 + \tau_{yz}^2 + \tau_{xz}^2) = 2Y^2$$

Y = uni-axial yield stress, For design use Y/n where n is factor of safety

Prof. Ramesh Singh




Locus of Yield



Prof. Ramesh Singh



Levy Mises Flow Eqn.



$$\varepsilon_x = \frac{\sigma_x}{E} - \frac{\nu}{E} (\sigma_y + \sigma_z)$$

Analogous to Elastic Equation

$$d\varepsilon_1 = \frac{d\bar{\varepsilon}}{\bar{\sigma}} \left[\sigma_1 - \frac{1}{2} (\sigma_2 + \sigma_3) \right]$$

$$d\varepsilon_2 = \frac{d\bar{\varepsilon}}{\bar{\sigma}} \left[\sigma_2 - \frac{1}{2} (\sigma_1 + \sigma_3) \right]$$

$$d\varepsilon_3 = \frac{d\bar{\varepsilon}}{\bar{\sigma}} \left[\sigma_3 - \frac{1}{2} (\sigma_1 + \sigma_2) \right]$$

Prof. Ramesh Singh



For Brittle Materials

- Brittle Materials
 - Hardened steels exhibit symmetry tension and compression so preferred failure is maximum normal stresses or principal stresses
 - Some materials which exhibit tension compression asymmetry such cast iron need a different failure theory such Mohr Coulomb




BACK UP



Prof. Ramesh Singh



Failure criteria a case study in composites




Failure stress for glass-fibers (Weibull Plot)




- Mean value of the tensile strength is 1623.3 MPa
- Maximum principle stress criteria is used for modeling

- $P(\sigma) = 1 - e^{\left(-\frac{\sigma}{\sigma_0}\right)^m}$
- $P = \frac{i-0.5}{n}$
- $Y_i = \ln\left(\ln\left\{\frac{1}{1-P(\sigma)}\right\}\right)$
- $X_i = \ln(\sigma_i)$
- $C = -m \ln(\sigma_0)$
- $Y_i = mX_i + C$
- $\sigma_m = \sigma_0 \Gamma\left(1 + \frac{1}{m}\right)$



Matrix failure and debonding

- Yielding takes place when the shear stress, τ , acting on a specific plane reaches a critical value, which is a function of the normal stress, σ_n , acting on that plane.



Elastic definition for traction separation law

$$\begin{Bmatrix} t_n \\ t_s \\ t_t \end{Bmatrix} = \begin{bmatrix} K_{nn} & & \\ & K_{ss} & \\ & & K_{tt} \end{bmatrix} \begin{Bmatrix} \varepsilon_n \\ \varepsilon_s \\ \varepsilon_t \end{Bmatrix}$$

For cohesive layer,
 $K_{nn} = K_{ss} = K_{tt} = 35$ Gpa
 $t_{nn} = t_{ss} = t_{tt} = 30$ Mpa

Maximum nominal stress criterion

Mohr–Coulomb model for matrix failure

$$\tau = c - \sigma \tan \phi$$

C -cohesion (yield strength of matrix under pure shear loading) = 30 MPa

ϕ -friction angle (10^0 - 30^0) = 10^0

$$\max \left\{ \frac{\langle t_n \rangle}{t_n^0}, \frac{t_s}{t_s^0}, \frac{t_t}{t_t^0} \right\}$$

